

DEVILBISS
NEW

Snake

Puts the bite on wet air.

The **DS-20 Desiccant Snake**, in-line compressed air dryer, removes moisture vapour and condensation in your airline down to 0.5% relative humidity in compressed air above -40°C.

Manufactured with quality, reinforced rubber hose and brass fittings, **the Snake** will give reliable service and can withstand pressures of up to 200 psi and temperatures to 65°C

Flexible, long and narrow with 1" brass ferrules and 1/4" brass thread connectors for a secure connection

Built-in elements remove dirt and oil as it passes through the Snake. Will flow up to 20 SCFM

The Desiccant Snake contains special desiccant and has a unique design that ensures maximum compressed air to desiccant contact time.

DESIGNED FOR USE IN:

- Painting priming areas
- Production lines
- Spray booths
- General workshop use
- For all types of air tools
- Quality control areas
- Clean, dry tyre air inflation

Part Numbers: DS20

Accessories Available: DeVilbiss offer you a full range of accessories and consumables including, hose kits and fittings, cleaning equipment and gun lubricants, mixing and viscosity cups, air supplied breathing apparatus, air filters, air and fluid regulators, disposable tank liners and Booth Filter

FREQUENTLY ASKED QUESTIONS:

Q: Why use a Desiccant Snake?

A: Less paint rectifications, "blooming" and longer tool life.

Q: Where should the Snake be installed?

A: After the filter regulator


Q: How long will the Desiccant Snake last?

A: Until saturated with water

Q: How will I know when to change the Snake?

A: You should use an **RHI-01** Indicator between the snake and the tool - you'll see when there's water in your airline.

Distributed by:



Stop killing your precious air tools!

Q: Are you damaging your expensive air tools?

Q: Are you getting poor finishing results?

Q: Is there moisture in your airline?

A: Then you need an RHI-01!

The RHI-01 Relative Humidity Indicator gives you positive indication of humidity in your compressed air. The RHI-01 can also be used with the Snake to reduce the humidity of all your compressed air.

Indicating desiccant starts changing color from blue to pink at 10% RH and is clear at 15% RH. Indicating desiccant will change back and forth numerous times.

FREQUENTLY ASKED QUESTIONS:

Q: Where should the Indicator be installed?

A: After your filter regulators and / or desiccant dryers

Q: What is the Relative Humidity of the compressed air when the indicator turns clear?

A: About 15%

Q: How long before the Indicator turns back to blue?

A: This will depend on the airflow through the fitting

Q: How many times will the beads change back & forth?

A: Many times. NB: oil and other contaminants will effect the service life.

Q: What's the pressure & temperature rating of the RHI-01?

A: 200 psi & 65°C

Q: How will I know when to replace the Indicator?

A: When the crystals no longer return to Blue when dry air is run through the fitting it is time to replace your RHI-01.

Q: What can I use to safely clean the sight glass?

A: Prepsol or a similar product

DRY AIR

WET AIR

FPT brass threads on each end for secure worry free connections.

Impact resistant sight glass

Stainless steel screens on each end.

DESIGNED FOR USE IN:

- Painting / priming areas
- Production lines
- Spray booths
- General workshop use
- For all types of air tools
- Quality control areas
- Testing Compressed air
- Home workshop use.

Part Numbers: RHI-01

IDEAL FOR USE WITH THE SNAKE!

DEVILBISS